

Hot Tub Troubleshooting Tip

Hot Tub Makes Unusual Noises

Step 1: Identify the Noise Source

- ❑ **Determine if the noise is coming from the pump, heater, or plumbing:** Listen carefully to locate the noise origin. Note the type of noise (humming, grinding, clicking) to help diagnose the issue.

Step 2: Check the Pump

- ❑ **Ensure the pump is properly secured:** Tighten any loose screws or bolts. If the pump is vibrating against something, add padding or adjust its position.
- ❑ **Inspect the pump impeller for debris or damage:** Turn off the power, open the pump housing, and remove any obstructions from the impeller. Replace the impeller if damaged.

Step 3: Inspect the Heater

- ❑ **Check for scale buildup or debris around the heating element.** Scale can cause the heater to make noises. If necessary, clean the heating element with a descaling solution.
- ❑ **Ensure the heater is properly secured:** Tighten any loose fittings and make sure the heater is firmly in place.

Step 4: Examine the Plumbing

- ❑ **Look for loose or vibrating pipes:** Tighten any loose pipe connections and secure pipes to reduce vibration noise. Use foam insulation to cushion pipes if needed.



**Love's
Hot Tubs**

Name Brand Spas Below Retail Pricing

208-353-2171

loveshottubs.com