

# Hot Tub Troubleshooting Tip

## Hot Tub Water Is Foamy

### Step 1: Check Water Chemistry

- ❑ **Test and balance pH, alkalinity, and sanitizer levels:** Use test strips or a test kit to measure and adjust the water's chemical levels. Proper balance prevents foaming.

### Step 2: Drain and Refill the Hot Tub

- ❑ **Drain the hot tub completely:** If foaming persists, drain all the water. Use a submersible pump for quicker draining.
- ❑ **Clean the interior surfaces:** Wipe down the hot tub shell with a mild, non-abrasive cleaner.
- ❑ **Refill with fresh water:** After cleaning, refill the hot tub with fresh water and balance the chemicals.

### Step 3: Use an Anti-Foam Product

- ❑ **Add a small amount of anti-foam product:** If foaming reoccurs, add an anti-foam product according to the instructions to quickly reduce foam.

### Step 4: Rinse Bathing Suits and Body

- ❑ **Rinse off soap, lotions, and detergents:** Before entering the hot tub, rinse off thoroughly to remove any residual soap or body products that can cause foam.



**Love's  
Hot Tubs**

Name Brand Spas Below Retail Pricing

208-353-2170

loveshottubs.com